LOWER ARM BOLT
10 x 1.5 mm

STABILIZER BAR
Check for bending or damage.

STABILIZER BAR BUSHING
Check for deterioration or damage.

8 x 1.25 mm

12 x 1.75 mm

10 x 1.5 mm

RAIDUS ROD
Check for bending or damage.

RAIDUS ROD COLLAR

SELF-LOCKING NUT
Replace

RADIUS ROD WASHER

RADIUS ROD WASHER

RADIUS ROD RUBBER BUSHINGS
Check for deterioration or damage.

LOWER ARM BUSHING
Check for deterioration or damage.

FRONT LOWER ARM
Check for damage.
Check ball joint for excessive wear or damage.

12-9