Exhaust Pipe and Muffler

Replacement (without CATA)

MUFFLER (DOHC)

FUEL TANK HEAT SHIELD

6 x 1.0 mm
10 N·m
(1.0 kg-m, 7 lb-ft)

6 x 1.0 mm
10 N·m (1.0 kg-m, 7 lb-ft)

MUFFLER (1.6ℓ 2-Carb)

8 x 1.25 mm
22 N·m (2.2 kg-m, 16 lb-ft)

GASKET
Replace

GASKET
Replace

EXAUST PIPE B

MUFFLER (1.4ℓ 2-Carb)

8 x 1.25 mm
22 N·m (2.2 kg-m, 16 lb-ft)

8 x 1.25 mm
22 N·m (2.2 kg-m 16 lb-ft)

EXAUST PIPE BRACKET

GASKETS
Replace

8 x 1.25 mm
22 N·m (2.2 kg-m, 16 lb-ft)

EXHAUST PIPE A (1.6ℓ)

EXHAUST PIPE BRACKET

GASKET
Replace

SELF-LOCKING NUT
10 x 1.25 mm
51 N·m (5.1 kg-m, 38 lb-ft)
Replace

EXHAUST PIPE BRACKETS

8 x 1.25 mm
22 N·m (2.2 kg-m, 16 lb-ft)
Replace
Tighten the bolts both sides
in turn more than one time.

8 x 1.25 mm
22 N·m (2.2 kg-m, 16 lb-ft)
Replace
Tighten the bolts both sides
in turn more than one time.

EXHAUST PIPE A (1.4ℓ)

8 x 1.25 mm
22 N·m (2.2 kg-m, 16 lb-ft)
Replace

SELF-LOCKING NUT
10 x 1.25 mm
51 N·m (5.1 kg-m, 38 lb-ft)
Replace

Replacement (with CATA)

FUEL TANK HEAT SHIELD

MUFFLER (DOHC)

6 x 1.0 mm
10 N·m
(1.0kg-m, 7 lb-ft)

MUFFLER (SOHC)

6 x 1.0 mm
10 N·m (1.0kg-m, 7 lb-ft)

10 x 1.25 mm
34 N·m (3.4 kg-m, 25 lb-ft)

8 x 1.25 mm
22 N·m (2.2kg-m, 16 lb-ft)

GASKET
Replace

GASKET
Replace

EXAUST PIPE B

GASKET
Replace

GASKET
Replace

6 x 1.0 mm
10 N·m
(1.0 kg-m, 7lb-ft)

8 x 1.25 mm
22 N·m (2.2 kg-m, 16lb-ft)

8 x 1.25 mm
22 N·m (2.2kg-m, 16 lb-ft)

EXHAUST PEPE BRACKETS

GASKET
Replace

8 x 1.25 mm
22 N·m (2.2kg-m, 16-ft)
Replace
Tighten the bolts both sides
in turn more than one time.

EXHAUSTPIPE BRACKET

EXHAUST PIPE A 8 x 1.25 mm
22 N·m (2.2 kg-m, 16 lb-ft)
Replace

SELF-LOCKING NUT
10 x 1.25 mm
51 N·m (5.1 kg-m, 38 lb-ft)
Replace