Dashboard

Component Removal/Installation

CLIP

UPPER TRIM PANEL
Carefully pull out the 9 clips
then remove the upper trim
panel.

SUNROOF SWITCH

CLOCK

**HAZARD WARNING LIGHT
SWITCH/REAR WINDOW DEFOGGER
SWITCH/REAR FOG LAMP SWITCH**

R. FRESH AIR VENTS

**PANEL BRIGHTNESS
CONTROLLER**

GLOVE BOX
NOTE: First remove the
damper mounting screw.

DAMPER

RING NUT

**POWER DOOR
MIRROR SWITCH**

**R. SIDE DEFROSTER
GARNISH**

ASHTRAY HOLDER

HOLDER

LATCH

COIN BOX

ASHTRAY

CIGARETTE LIGHTER ASSEMBLY
Remove the ring nut and remove the
cigarette lighter together with the
protector.

RADIO PANEL ASSEMBLY
(page 14-50)

STEREO CASSETTE/RADIO
Disconnect wire harness
(antenna cable).

**DASHBOARD LOWER
PANEL**